

UK Adhesive Recommendation for EarthWerks Glue Down I Dryback

Supplier	Recommended adhesive	Notch Trowel
Bostik	Bostik's Best	A2
	Bostik Power Elastic	A2
	Nibofloor 800	A2
F-Ball	F44	A2
	F46	A1
	F48 plus	A2
Henkel	Thomsit K 188E	A2
	Thomsit K188 S	A2
Mapei	Ultrabond Eco 4 LVT	A2
	Ultrabond Eco V4 SP	A2
	Ultrabond Eco 360	A2
	Ultrabond Eco VS90 Plus	A2
PCI	UKL 302	
	PKL326	
Schönox	Schönox DUROCOLL (fibre reinforced, strong dispersiopl adhesive)	A1 / A2
	Schönox PU 900 (Solvent free 2 component PU adhesive)	A2
Stauf	Stauf D 50 EC1 plus	A2
	Stauf D 37 EC1	A2
	Stauf R 105 EC1 plus	A2
Uzin	Uzin KE 2000S	A2 (A1)
	KE 66E	A2 (A1)
	Sigan Elements	Rolls
Wakol	Wakol D 3307	A2
	Wakol D 3320	A2
	Wakol D 3360	A2
Wulff	WULFF Ultra-Strong	A2
	WULFF Supra-Strong	A2
	WULFF Multi-Strong	A2

Please follow also to our separate LVT - Glue Down installation guideline.

Equivalent adhesives may be used - please follow the instructions of the respective adhesive supplier.

Contact Europe

Tel : + 32 87 30 68 50
Fax : +32 87 32 30 39
www.earthwerks.eu.com

Contact UK

Free phone: 0800 689 1459
sales@earthwerks.co.uk
www.earthwerks.co.uk

EarthWerks is a division of Swift -Train Company

07.05.2019